

www.DCMUGEN.com

DCMUGEN STEP BY STEP GUIDE

FOLLOW THE STEPS BELOW TO EASILY INSTALL YOUR PRIVACY SCREEN PROTECTOR. FOLLOW THE GUIDE CAREFULLY TO AVOID ALIGNMENT ISSUES, DUST, OR AIR BUBBLES.

WHAT YOU NEED

PRIVACY SCREEN PROTECTOR

CLEANING CLOTH

SQUEEGEE (CREDIT CARD OR BUSINESS CARD)

*NOTE: SOME OF OUR PRIVACY SCREEN PROTECTORS MAY ONLY HAVE 1 TAB TO PULL OFF. ONCE YOU APPLY THE FIRST STEPS INVOLVING THE ONE TAB YOU ARE DONE. IF YOU HAVE A PRIVACY SCREEN PROTECTOR WITH 2 TABS THEN YOU WILL NEED TO COMPLETE THE FULL GUIDE.

*IMPORTANT: BEFORE STARTING YOUR APPLICATION, PLEASE DO A QUICK CHECK TO ENSURE YOUR TABS WILL PULL OF THE PROTECTIVE LAYER PROPERLY. DO A TEST PULL ON EACH TAB TO ENSURE THAT IT PULLS OFF THE FILM. IF YOU FIND THAT THE TAB DOES NOT PULL OFF ANY PROTECTION FILM PLEASE REFER TO OUR TROUBLESHOOTING SECTION AT THE BOTTOM OF THIS GUIDE.

STARTING...

1 MAKE SURE YOUR INTENDED SCREEN SURFACE AREA IS COMPLETELY CLEAN OF DUST, GRIME, AND OIL. YOU WON'T BE ABLE TO REMOVE THEM AFTER YOU INSTALL THE PROTECTOR. IF YOU GET DUST OR LINT ON THE STICKY SIDE OF THE PROTECTOR, YOU CAN TRY AND REMOVE THEM WITH A TWEEZERS.

ALTERNATIVELY YOU CAN ALSO USE SCOTCH TAPE AND PULL OFF DEBRIS USING THIS METHOD AS WELL. HOWEVER, YOU WILL NEED TO BE MINDFUL TO APPLY AND PULL BACK QUICKLY TO AVOID LEAVING STICKY TAPE RESIDUE.

WE HAVE INCLUDED A LINT FREE CLEANING CLOTH FOR YOUR USE.

2 WHATEVER YOU DO, DO NOT TOUCH THE STICKY SIDE OF THE PROTECTOR. YOUR OILS WEAKEN THE GLUE AND THERE'S A GOOD CHANCE OF LEAVING A PERMANENT FINGERPRINT. THIS REFERENCE IS TO TAB 1 SIDE OF THE SCREEN PROTECTOR.

3 FIND A GOOD SQUEEGEE. AVOID USING CREDIT CARDS WITH HARD OR ROUGH EDGES THE PROTECTOR CAN BE SCRATCHED OR WARPED IF YOU USE TOO MUCH PRESSURE OR SOMETHING TOO HARD. I FOUND AN OLD PHONE CARD WHICH WAS MADE OF REALLY SOFT PLASTIC. WE WOULD ALSO RECOMMEND USING A CARD STOCK BUSINESS CARD.

4 WITHOUT REMOVING THE BACKING (TAB 1), ALIGN THE SCREEN PROTECTOR ON YOUR DEVICE MAKING SURE THAT IS ALIGNED PROPERLY.

5 PEEL OFF TAB 1. ALIGN THE EDGE OF THE SCREEN PROTECTOR TO THE EDGES OF YOUR SCREEN. ONCE YOU HAVE THE CORRECT ALIGNMENT APPLY THE NEWLY EXPOSED SIDE OF THE SCREEN PROTECTOR ONTO THE SURFACE OF YOUR SCREEN.

*FOR BEST RESULTS, PEEL OFF HALF THE SCREEN PROTECTOR TAB 1 FILM. ALIGN THE NEWLY EXPOSED SCREEN PROTECTOR TO THE DEVICE SCREEN. HOLDING DOWN THE NEWLY ATTACHED SIDE, SLOWLY PEEL BACK TAB 1. AS YOU PEEL IT BACK, USE THE SQUEEGIE TO APPLY THE PROTECTOR TO YOUR DEVICE. THE SLOWER YOU GO, THE LESS LIKELY YOU'LL GET AIR BUBBLES.

6 CHECK THE ALIGNMENT ON BOTH SIDES. IF IT LOOKS CROOKED, LIFT THE SCREEN PROTECTOR AND REPEAT STEP 5.

7 SMOOTH OUT THE SURFACE OF THE NEWLY APPLIED SCREEN PROTECTOR TO WORK OUT MINOR BUBBLES THAT MAY BE NEAR THE EDGES. (IF YOUR SCREEN PROTECTOR IS MISALIGNED DON'T WORRY, YOU CAN PEEL IT OFF CAREFULLY AND REAPPLY IT).

8 REMOVE THE LAST LAYER ON THE SCREEN PROTECTOR BY PULLING UPWARDS ON TAB 2. (SOME PRIVACY SCREEN PROTECTORS DO NOT HAVE A TAB 2) ONCE YOU APPLY TAB 1 TO THE SCREEN YOU ARE DONE.

9 YOU'RE DONE.

FOR BEST RESULT REFERENCE THE VIDEO FOR A STEP BY STEP VIDEO INSTRUCTION.

BROUGHT TO YOU BY DCMUGEN.COM